# SnowGuardWarehouse.com Ph: 814-786-9085 Mail@JosephJenkins.com

MJ Mullane Fit Rite – FR122BR – Bronze 2 Pipe Brackets with Brass Base Plate Snow Guard for Composite Roofing

**Snow Guards** 

PART 1 - GENERAL

### 1.1 SUMMARY

### A. WORK INCLUDES

- 1. FR122BR snow guard that attaches directly to the roof
- 2. Provide appropriate snow guard and fasteners for the roof system.

## **B. RELATED SECTIONS**

- 1. Section 07310: Shingles, MasterFormat<sup>™</sup>2004 07 31 00
- 2. Section 07320: Roofing Tiles, MasterFormat<sup>™</sup> 2004 07 32 00
- 3. Section 07410: Metal Roof Panels, MasterFormat<sup>™</sup>2004 07 41 10
- 4. Section 07600: Flashing and Sheet Metal, MasterFormat<sup>™</sup> 2004 07 60 00
- 5. Section 07610: Sheet Metal Roofing, MasterFormat<sup>™</sup>2004 07 61 00
- Section 07613 Standing Seam Metal Roofing, MasterFormat<sup>™</sup> 2004 07 61
  13
- 7. Section 07720: Roof Accessories, MasterFormat<sup>™</sup>2004 07 72 00
- 8. Division 7: Thermal and Moisture Protection

## 1.2 SYSTEM DESCRIPTION

### A. COMPONENTS:

- 1. FR122BR Snow guard system consists of snow guard brackets assembled with (2) brass bolts, nuts and washers, riveted base plate. Width and Length of plate to match size of roofing material.
- 2. Tubing (Snow Fence).
- 3. Couplings.
- 4. End Caps.



- 5. Fasteners
- 6 Sealant (if required by roof manufacturer).
  - a. To be roof manufacturer approved.

## B. DESIGN REQUIREMENTS:

- 1. Bracket spacing to be recommended by snow guard manufacturer or building engineer.
- 2. Minimum six (6) fasteners per snow guard.
- 3. It is important to design new structures or assess existing structures to make sure that they can withstand retained snow loads.

### 1.3 SUBMITTAL

A. Submit manufacturer's specifications, standard detail drawings, and recommended layout and installation instructions.

## 1.4 QUALITY ASSURANCE

A. Installer to be experienced in the installation of specified roofing material and snow guards for no less than 5 years in the area of the project.

## 1.5 DELIVERY / STORAGE / HANDLING

A. Inspect material upon delivery and order replacements for any missing items. Keep material dry, covered and off the ground until installed.

### PART 2 - PRODUCTS

## 2.1 MANUFACTURER

A. Berger Building Products, Inc. 805 Pennsylvania Blvd.; Feasterville, PA 19053; Tel: 800-523-8852; Email: Info@BergerBP.com, Web: www.bergerbp.com

### 2.2 MATERIALS

- A. Snow Guard Bracket FR122BR
  - 1. Castings: Cast Bronze ASTM B 584 Alloy C84400



- 2. Base Plate: Brass (0.125"), Half Hard Brass, CDA 260, Rivets (4), 9/16" Flat Head Copper. Width and Length of plate to match size of roofing material
- C. Tubing:
  - 1. Brass: (RBP800-12), Red Brass, 0.50" ID, ASTM B-43 AND ALLOY 230
- D. Couplings:
  - 1. Brass (RBCON800), Red Brass, 0.50" ID, ASTM B-43 AND ALLOY 230
- E. End Caps:
  - 1. Brass (RBPEC800), Red Brass, 0.50" ID, ASTM B-43 AND ALLOY 230
- F. Fasteners (can be purchased from others) to be compatible with chosen roof application and meet specified pull out values as shown in load test data.

### 2.3 FINISH:

A. Mill Finish – standard

PART 3 - EXECUTION

#### 3.1 EXAMINATION

- A. Substrate
  - Inspect structure on which snow guard system is to be installed and verify that it will withstand any additional loading that it may incur. Notify general contractor of any deficiencies before installing Berger Snow Guards.
  - 2. Verify that roofing material has been installed correctly prior to installing snow

### 3.2 INSTALLATION

A. Comply with architectural drawings and snow guard manufacturer's recommendations for location of system. Comply with manufacturer's written installation instructions for installation and layout

Document Version 05-2013

07 72 53 Snow Guards